

This specification covers **InhibiCrobe GlassMat** Antimicrobial Glass Cloth-Reinforced System, a high-performance antimicrobial system consisting of an antimicrobial vertical-substrate concrete pretreatment, an antimicrobial block-filler, and antimicrobial flexible hybrid basecoat reinforced with glass cloth mat. A 2nd application of the flexible hybrid basecoat is applied, followed by an application of an antimicrobial glass and fiber-reinforced epoxy build coat. This base is top coated with a high-performance antimicrobial urethane. This smooth, cloth reinforced wall system is easy to wash and is suited for use in areas where superior chemical resistance, durability and UV-stability are crucial.

1.00 GENERAL

1.01 SECTION INCLUDES

- A. Preparation of concrete or block substrate
- B. Apply antimicrobial concrete/block pretreatment
- C. Apply antimicrobial concrete/block filler
- D. Apply antimicrobial hybrid basecoat
- E. Apply glass cloth mat
- F. Apply antimicrobial hybrid basecoat
- G. Apply antimicrobial glass and fiber-reinforced epoxy coating
- H. Apply antimicrobial urethane topcoat

Specifier Notes: Edit the following list as required by the project. List other sections with work directly related to the floor coating.

1.02 RELATED SECTIONS

- A. Section 03 30 00 – Cast-In-Place Concrete: [existing or] new slab.
- B. Section 03 35 00 – Concrete Finishing: specific chemicals on slab.
- C. Section 03 39 00 - Concrete Curing
- D. Section 03 01 00 – Concrete Rehabilitation

1.04 REFERENCES STANDARDS

- A. For reference standards tests & results refer to Manufactures Product Data Sheets

1.05 ADMINISTRATIVE REQUIRMENTS

- A. Pre installation meeting call if needed.
- B. Involve: Owner, Contractor, Consultant(s), sub-contractors effected

1.06 SUBMITTALS

- A. Samples: forward 4- 4" x 4" color samples representative of finish product for review.
- B. Manufactures' Instructions: submit to Consultant for review.
- C. Sustainable Design Submittals: as required by other sections.

1.07 CLOSEOUT SUBMITTALS

- A. Applicable testing/performance data certification(s)
- B. Certification(s) of compliance with owner's performance spec, if required
- C. Cleaning, care and maintenance instructions
- D. Material warranty information

1.08 QUALITY ASSURANCE

- A. Regulatory Agency Sustainability Approvals
- B. Applicator: Use applicator experienced in application of specified materials for a minimum of [5] [Five] years on projects of similar size and complexity. Provide list of completed projects including project name and location, name of architect, name of material manufacturer, and approximate quantity of materials applied.
- C. Applicator's Personnel: Employ only persons trained for application of specified materials.

1.09 DELIVERY, STORAGE, AND HANDLING

- A. Delivery: Deliver materials to site in manufacturer's original, unopened containers and packaging, with labels clearly identifying product name, manufacturer, batch or lot number, and date of manufacture. Do not store in direct sunlight or high heat conditions.
- B. Packaging Waste Management
- C. Storage:
 - 1. Store materials in accordance with manufacturer's instructions.
 - 2. Keep containers sealed until ready for use.
 - 3. Do not subject material to excessive heat or freezing; do not apply material that has been subjected to excessive heat or freezing. Material subjected to excessive heat or freezing shall be separated from inventory and destroyed by mixing all three components. The solid reacted product shall be disposed of in environmentally sound and regulatory compliant manner.
 - 4. Shelf life: 1 year after date of manufacture, in unopened containers, under normal conditions.
- D. Handling: Protect materials during handling and application to prevent damage or contamination.
- E. Condition materials for use to 65°F – 75°F (18°C - 24°C) for 24 hours prior to application.

1.11 SITE CONDITIONS

- A. Ambient Conditions
 - 1. Do not apply materials if floor or air temperature is below 65°F (18°C).
 - 2. Do not apply materials if relative humidity is above 85 percent or within 5° of dew point at time of application.
- B. Existing Conditions

1. Utilities, including electric, water, heat and finished lighting to be supplied by General Contractor.
2. Maintain room temperature between 65°F – 75°F (18°C - 24°C) for 48 hours before, during and 48 hours after installation, or until cured.
3. At the time of application ensure the minimum substrate temperature is above 60°F (15°C) and the substrate temperature is 5°F (3°C) above the measured dew point at the time of application.
4. Erect suitable barriers and post legible signs at points of entry to prevent traffic and trades from entering the work area during application and cure period of the floor.
- .5 Protection of finished floor from damage by subsequent trades shall be the responsibility of the General Contractor.

1.12 MANUFACTURER WARRANTY

- A. Provide warranty covering materials for a period of [1] [one] year after date of installation
- B. Installer to provide suitable warranty covering workmanship

2.00 PRODUCTS

2.01 MANUFACTURER

- A. Protective Industrial Polymers www.protectpoly.com (866) 361-3331
- B. 7875 Bliss Parkway, North Ridgeville, Ohio 44039

2.02 MATERIALS

- A. Protect AM-PT-BW Antimicrobial Concrete/Block Pretreatment
- B. Protect AM-Block Fill Antimicrobial Block Filler
- C. Protect AM-W-Flex Antimicrobial Hybrid Basecoat
- D. 2 or 4 oz. Glass Cloth Mat
- E. Protect AM-W-Flex Antimicrobial Hybrid Basecoat
- F. Protect AM-W-GRE Antimicrobial Glass and Fiber-Reinforced Epoxy Coating
- G. Protect AM-W-URTC Antimicrobial Urethane Topcoat

2.03 QUALITY CONTROL

- A. Tests and Inspections: as required by Manufacturer.
- B. Non-Conforming Work: remove immediately and dispose off site.
- C. Coordination of Other Tests and Inspections

3.00 EXECUTION

3.01 APPLICATOR

- A. Must be a recognized contractor of Protective Industrial Polymers

3.02 EXAMINATION

- A. Substrate:

1. Free of curing membranes, silicate surface hardener, paint, or sealer and be structurally sound.
 2. If you suspect concrete has been treated or sealed, proceed with complete removal process.
 3. Consult your PIP representative for further instruction if silicate hardeners or membranes have been utilized.
- B. Moisture:
1. Use only if the concrete has a maximum internal relative humidity of 75% using ASTM F2170.
- C. Vapor / Contamination:
1. Testing for MVT does not guarantee against future problems.
 2. If there is no known vapor barrier or the vapor barrier is inadequate, there is an elevated risk of bond failure.
 3. Other factors including the migration of oils, chemicals, excessive salts, or Alkali Silica Reaction (ASR) from the concrete from may also elevate the risk of adhesion difficulties.
 4. Consult your PIP representative for approved mitigation treatments.
- D. Temperature:
1. During the application and cure of the coating, the substrate temperature, material temperature and room conditions must be maintained between 18°C (65°F) and 32°C (90°F).
- E. Humidity:
1. Relative Humidity (RH) should be limited to 30-80%.
 2. DO NOT apply coatings unless the surface temperature is more than five degree over the dew point.

3.03 PREPARATION

- A. Remove surface dirt, grease, oil, and contaminants by detergent scrubbing and rinse with clean (clear) water.
- B. Mechanical Preparation: Blasting or grinding the surface is the preferred method of preparation.
- C. The success of industrial diamond grinding as a concrete preparation method will vary depending on technique and the hardness of the concrete.

3.04 JOINTS

- A. All non moving joints (control joints) may be filled with a semi-rigid joint compound such as Protect JF-Epoxy or Protect JF-Polyurea.
- B. Construction joints may need to be re-built and re-cut depending on conditions.
- C. Isolation or expansion joints should be left uncoated.

3.05 MIXING

- A. Mix material in appropriate vessel as stated in the product's corresponding Technical Data Sheet.
- B. Mix material as directed in the product's corresponding Technical Data Sheet.

3.06 APPLICATION EQUIPMENT

- A. Protective equipment and clothing as called for in the MSDS
- B. Jiffy® Mixer Blade model ES
- C. Clean container for mixing material
- D. Low speed high torque drill motor
- E. High quality short nap roller covers - ¼ - 3/8 inch nap
- F. Application squeegee
- G. High Pressure Airless Sprayer
- H. Spring Steel Trowel

3.07 APPLICATION

- A. Protect AM-PT BW Anti-Microbial Concrete Pretreatment
 - 1. Dampen concrete with water by using the same sprayer set up and technique used to apply the AM-PT BW as seen below. Do not puddle water.
Apply AM-PT BW with a high pressure airless sprayer using a 0.17 - 0.19" degree fan tip within 15 minutes of dampening the concrete for best results. Position the spray tip approximately 8"-10" (200-300mm) from the concrete surface, using an overlapping spray pattern. Apply at a rate of 200 sq. ft per gallon (5 SM/L by applying in two passes applying the second pass immediately after the first has penetrated the surface (normally 5 to 20 minutes). **DO NOT ALLOW TO DRY.** Apply the second application at 90° to the first (cross shape). Completely saturate the substrate but **DO NOT PUDDLE.** Use a clean broom to distribute ALL puddles immediately.
- B. Protect AM Block Fill
 - 1. Apply the properly mixed block filler primer to the treated concrete substrate using a spring steel trowel to fill in bug-holes and voids.
- C. Protect AM W Flex Flexible Basecoat
 - 1. Apply the properly mixed coating to substrate with a 3/8" nap roller.
- D. Application of 2 or 4 oz. glass fabric into wet basecoat.
- E. Protect AM W Flex Flexible Basecoat
 - 1. Apply the properly mixed coating to saturate fabric with a 3/8" nap roller.
- F. Protect AM W GRE Glass and Fiber reinforced Basecoat
 - 1. Apply the properly mixed coating with a 3/8" nap roller.
- G. Protect AM W URTC Antimicrobial Urethane Topcoat
 - 1. Apply the properly mixed antimicrobial topcoat by pan rolling with a 3/8" non shed roller.
- H. Tolerances:
 - 1. InhibiCrobe GlassMat: 20-30 mils (with 2 oz. cloth)
30-40 mils (with 4 oz. cloth)

3.08 SPEADING RATE

1. Antimicrobial Pre-treatment - the degree of porosity in the concrete will greatly affect coverage rates. Typical consumption rate for pre-treatment is 200 SF/gal).
2. Antimicrobial Block Filler- is applied at a consumption rate required to fill voids and smooth surface. Consumption varies according to substrate.
3. Antimicrobial Flexible Basecoat- is applied at 6-10 mils (160-267 SF/Gal.)
4. Antimicrobial Glass and Fiber Reinforced Basecoat- is applied at 6-10 mils (160-267 SF/Gal.)

5. Antimicrobial Topcoat is applied at 3.5-6 mils (267-458 SF/gal).

3.09 CURING

- A. Allow the coating to cure (dry) for a minimum 24 hours after application at 24°C (75°F) and 50% RH before opening the wall to service.
- B. Full coating properties mat take up to 7 days to develop.

3.10 REPAIR

- A. Repair gouges, chip outs, and scratches as soon as possible to prevent moisture and chemical under cutting and permanent damage to the coating.

3.11 RECOAT

- A. Refer to appropriate product's Technical Data Sheet for recoat timetables and allowable recoat parameters as presented by the manufacturer.
- B. If the re-coat window has expired, the prior cured coating surface must be sanded with 100 grit sand paper or sanding screen.
- C. Sand to a uniform dulled surface.
- D. Remove all sanding debris with a vacuum and damp mop.
- E. Scrub with detergent and rinse with clean (clear) water.
- F. Surface must be dry before recoating.

3.12 SITE QUALITY CONTROL

- A. Site Tests and Inspections: per manufacturer's guidelines
- B. Non-Conforming Work: remove immediately and dispose off site

3.13 ADJUSTING

- A. Permitted only upon manufacturer's approval in writing

3.14 CLEANING

- A. Remove masking, draping, and other protection from adjacent surfaces.
- B. Remove remaining materials and debris from job site and dispose of them according with local rules and regulations. Leave area in clean condition free of debris.

3.15 CLOSEOUT ACTIVITIES

- A. Notify manufacturer of completion of installation

- B. Forward operation and maintenance data to owner/owner's rep
- C. Forward effective warranty date and information to owner/owner's rep

3.16 PROTECTION

- A. Pointed items or heavy items impacting the wall may cause chipping or concrete pop out damage.

3.17 MAINTENANCE

- A. Allow coating to cure at least one week before cleaning by mechanical means (IE: sweeper, scrubber, disc buffer).
- B. Increased life of the wall will be seen with proper maintenance and will help maintain a fresh appearance of your new Protective Industrial Polymers wall.
- C. Regularly clean ground in dirt and grit which can quickly dull the finish, decreasing the life of the coating.
- D. Splashes from Spills should be removed quickly as certain chemicals may stain and can permanently damage the finish.
- E. Heavy objects dragged across the surface will scratch all wall coatings. Avoid gouging or scratching the surface.

END OF SECTION

See additional legal information below

Protective Industrial Polymers may change individual product properties without notice. All sales subject to Protective Industrial Polymers' current terms and conditions of sale. Current terms and conditions can be obtained by calling 866-361-3331. The user of the Protective Industrial Polymers' product(s) must test the product(s) for suitability for the intended purpose and application before proceeding with full application of the product(s).

The most current Technical Data Sheets, System Sheets and SDS information are available at www.protectpoly.com, or by calling 866-361-3331. Installers and handlers of any Protective Industrial Polymers material must read and follow all printed information on Product Labels, Technical Data Sheets, System Data Sheets and SDS Sheets. Nothing contained in any Protective Industrial Polymers material relieves the installer, handler, owner or owner's rep of the obligation to read and follow stated warnings and instructions as presented in these referenced documents.

All information provided by Protective Industrial Polymers concerning its products, including but not limited to, advice and recommendations relating to the application and use of Protective Industrial Polymers products, is provided in good faith based on Protective Industrial Polymers' knowledge of its products when properly transported, stored, handled and applied under normal conditions in accordance with Protective Industrial Polymers' written instructions. With regard to field practice, the differences in materials, substrates, storage and handling conditions, actual site conditions and other factors outside of Protective Industrial Polymers' control are such that Protective Industrial Polymers assumes no liability for the provision of such information, advice, recommendations or instructions related to its products, nor shall any legal relationship be created by or arise from the provision of such information, advice, recommendations or instructions related to its products.